

7-9VDC

IN

MIDI

OUT

OUT L1

OUT R1

OUT L2

OUT R2

MEMORY

USB

RESET CLOCK1 CLOCK2

RESET IN CLOCK IN

T1

T2




T3

T4

T5

T6

T7




MENU

SHIFT COPY CLEAR

PAT GEN VOICE PERF STEP MENU LOAD/SAVE

OSC AEG MOD FM CLICK FILTER LFO MIX



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

DRUM1 DRUM2 DRUM3 SNARE CLP/CY HH OH

DRUM 1

MUTE

DRUM 2

MUTE

DRUM 3

MUTE

SNARE

MUTE

CYM/CLAP

MUTE

OH/HH

MUTE